



# Voreinstellung Wassermenge für Vario-DP



## Einstelltabelle

Voreinstellung Ventil:	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6	6	7	7	7	7	8
Wassermenge in l/h:	20	20	25	25	35	40	45	55	65	80	90	100	115	135	145	160	170	185	200	215	230	245	260	275	290	300	315	330	340
Differenzdruck: 15–70 kPa																													

### Beispiel Ventilvoreinstellung



- 1 Anzeige Voreinstellung
- 2 Haupteinstellwert
- 3 Feineinstellung